

# MARINE DOOR

Stainless Steel Door




Motor Operated  
Face of Wall Mounted


Page#:

Page 1


LG - Left Guide  
RG - Right Guide  
B - Bracket  
GW - Guide Width  
GD - Guide Depth




COIL SIDE ELEVATION



VERTICAL SECTION A - A



GUIDE DETAIL B - B



CURTAIN DETAIL

## Notes:

- See Page 2 for more options.
- All metric conversions of dimensions are shown in brackets [ ].

SALES REP:

CUSTOMER:

JOB NAME:

NUMBER:

Manufactured by:

**Alpine**<sup>®</sup>  
OVERHEAD DOORS, INC.


8 HULSE ROAD EAST SETAUKET, N.Y. 11733

TEL: (631)473-9300 FAX: (631)642-0800


© COPYRIGHT FEB. 2005




Motor Operated  
Face of Wall Mounted



BOTTOM BAR DETAIL



HOOD SHAPES AVAILABLE FOR THIS DOOR



FLAME BAFFLE DETAIL

Distributed By:

Call your Alpine representative for additional options and safty products to help find the best Alpine door to suit your needs.

Manufactured by:

**Alpine®**  
OVERHEAD DOORS, INC.  
8 HULSE ROAD EAST SETAUKET, N.Y. 11733  
TEL: (631)473-9300 FAX: (631)642-0800  
© COPYRIGHT MAY 2007

# MARINE DOOR

Stainless Steel Door


NOTE: MAXIMUM PIPE  
DEFLECTION ON ANY SIZE  
DOOR IS .034



Page#:

Page 3

Finding the minimum required operation for the size door you need.




## Operator Legend

To use Chart: Find where your door width and height meet to find the minimum operation that may be used for that door size.

For example: The blue line indicates a Hand Chain Operation. Any size door on that line or above that line may use a Hand Chain, including the door sizes that fall into the Manual push up door. But, The Manual push up door may not be used for any door size below the line representing Push up operation. For any door size larger than what is represented here please consult your Alpine Overhead Doors, Inc. Factory. This Graph is for reference only, subject to change without notice.

Finding the minimum required bracket size for the door you need.



NOTE: Bracket sizes may vary based on gauge of curtain. Bracket size is directly related to the pipe low moment arm deflection (not more than .03 inches per foot).

To use Chart: Find where your door width and height meet to find the minimum bracket size for your door. For any door size larger than what is represented here please consult your Alpine Overhead Doors, Inc. Factory. This Graph is for reference only, subject to change without notice.

Distributed By:

Manufactured by:

**Alpine**<sup>®</sup>  
OVERHEAD DOORS, INC.

8 HULSE ROAD EAST SETAUKET, N.Y. 11733

TEL: (631)473-9300 FAX: (631)642-0800

© COPYRIGHT DEC 2006